

Note: \* = Optional

Item No.	TE Part No.	Description	DHBQ 26G-BN	DHBQ 26G-BL	DHBQ 32G-BN	DHBQ 32G-BL	DHBQ 32R/S-BN	DHBQ 32R/S-BL	DHBQ 38R/S-BN	DHBQ 38R/S-BL
1	S13113	Handle Bracket	2	2	2	2	2	2	2	2
2	S13134	Handle Bracket Insulator	2	2	2	2	2	2	2	2
3	S12351	Tube Handle 24.6" S/S Handle	1	1						
4	S12352	Tube Handle 30.6" S/S Handle			1	1	1	1		
5	S12353	Tube Handle 36.6" S/S Handle							1	1
6	S15343	Hood Thermometer / Bezel / Nut	1	1	1	1	1	1	1	1
7	S22141	Bracket, Mount Igniter, IR, Rotis					1	1	1	1
8	S23231-26Y	26" Hood Assembly	1	1						
9	S23231-32Y	32" Hood Assembly			1	1	1	1		
10	S23231-38Y	38" Hood Assembly							1	1
11	S13841	26" Warming Rack	1	1						
12	S13842	32" Warming Rack			1	1	1	1		
13	S13889	38" Warming Rack							1	1
14	S21813	Motor Bracket	1*	1*	1*	1*	1	1	1	1
15	S16340	Rotisserie Motor	1*	1*	1*	1*	1	1	1	1
16	S23227-26	Top, Rear Hood Cover, 26"	1	1						
17	S23227-32	Top, Rear Hood Cover, 32"			1	1	1	1		
18	S23227-38	Top, Rear Hood Cover, 38"							1	1
19	S23216	Bracket, Ignition Module	1	1	1	1	1	1	1	1
20	S16270	Halogen Light	1	1	2	2	2	2	2	2
21	S16318	Led, Red	2	2	3	3	4	4	4	4
22	S13330	Infrared Rotisserie Burner					1	1	1	1
23	S13883	Stainless Steel Spit Rod (26"/32")	1*	1*	1*	1*	1	1	1	1
24	S13890	Stainless Steel Spit Rod (38")							1	1
25	S16303	Safety Thermocouple					1	1	1	1
26	S16268	LR Igniter, Rotisserie					1	1	1	1
27	S22083	Cover, IR Igniter, Rotisserie					1	1	1	1
28	S13865	Stainless Steel Meat Forks	1*	1*	1*	1*	1	1	1	1
29	S23220-26	Bottom, Rear Hood Cover, 26"	1	1						
30	S23220-32	Bottom, Rear Hood Cover, 32"			1	1	1	1		
31	S23220-38	Bottom, Rear Hood Cover, 38"							1	1
32	S23206	Baffle, Air Stop	2	2	3	3	3	3	3	3
33	S16272	Battery Pack	1	1	1	1	1	1	1	1
34	S23202-26GY1	Front Panel, DHBQ26G	1	1						
35	S23202-32GY1	Front Panel, DHBQ32G			1	1				
36	S23202-32RY1	Front Panel, DHBQ32R					1	1		
37	S23202-38RY1	Front Panel, DHBQ38R							1	1
38	S23203-26	26" Drip Pan Handle	1	1						
39	S23203-32	32" Drip Pan Handle			1	1	1	1		
40	S23203-38	38" Drip Pan Handle							1	1
41	S13163	Delta Heat Logo	1	1	1	1	1	1	1	1
42	S14232	Logo Clip	2	2	2	2	2	2	2	2
43	S13162-02	Delta Heat Knob	2	2	3	3	4	4	4	4
44a	S13191	Knob, Bezel, (No Graphics)	2	2	3	3	4	4	4	4
44b	S13165	Knob, Bezel, (With Graphics)	2	2	3	3	4	4	4	4
45	S12751YN S12751YL	Manifold Assembly (26") NG Manifold Assembly (26") LP	1	1						
46	S12752GYN S12752GYL	Manifold Assembly (32G") NG Manifold Assembly (32G") LP			1	1				
47	S12752RYN S12752RYL	Manifold Assembly (32R") NG Manifold Assembly (32R") LP					1	1		
48	S12753YN S12753YL	Manifold Assembly (38") NG Manifold Assembly (38") LP							1	1
49	S16273	Light Switch	1	1	1	1	1	1	1	1
50	S23229	Spacer, Briquette Tray	4	4	6	6	6	6	6	6
51	S16274	Spark Igniter (U-Burner)	1	1	2	2	2	2	2	2
52	S13365	Stainless Steel U-Burner	2	2	3	3	3	3	3	3
53	S23218-38Y	Briquette Tray Assembly, 26, 38	2	2					3/2	3/2
54	S23218-32Y	Briquette Tray Assembly, 32			3	3	3/2	3/2		

Note: \* - Optional