

Note: * = Optional

| Item No. | TE Part No. | Description | DHBQ 26G-BN | DHBQ 26G-BL | DHBQ 32G-BN | DHBQ 32G-BL | DHBQ 32R/S-BN | DHBQ 32R/S-BL | DHBQ 38R/S-BN | DHBQ 38R/S-BL |
|----------|------------------------|--|-------------|-------------|-------------|-------------|---------------|---------------|---------------|---------------|
| 1 | S13113 | Handle Bracket | 2 | 2 | 2 | 2 | 2 | 2 | 2 | 2 |
| 2 | S13134 | Handle Bracket Insulator | 2 | 2 | 2 | 2 | 2 | 2 | 2 | 2 |
| 3 | S12351 | Tube Handle 24.6" S/S Handle | 1 | 1 | | | | | | |
| 4 | S12352 | Tube Handle 30.6" S/S Handle | | | 1 | 1 | 1 | 1 | | |
| 5 | S12353 | Tube Handle 36.6" S/S Handle | | | | | | | 1 | 1 |
| 6 | S15343 | Hood Thermometer / Bezel / Nut | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| 7 | S22141 | Bracket, Mount Igniter, IR, Rotis | | | | | 1 | 1 | 1 | 1 |
| 8 | S23231-26Y | 26" Hood Assembly | 1 | 1 | | | | | | |
| 9 | S23231-32Y | 32" Hood Assembly | | | 1 | 1 | 1 | 1 | | |
| 10 | S23231-38Y | 38" Hood Assembly | | | | | | | 1 | 1 |
| 11 | S13841 | 26" Warming Rack | 1 | 1 | | | | | | |
| 12 | S13842 | 32" Warming Rack | | | 1 | 1 | 1 | 1 | | |
| 13 | S13889 | 38" Warming Rack | | | | | | | 1 | 1 |
| 14 | S21813 | Motor Bracket | 1* | 1* | 1* | 1* | 1 | 1 | 1 | 1 |
| 15 | S16340 | Rotisserie Motor | 1* | 1* | 1* | 1* | 1 | 1 | 1 | 1 |
| 16 | S23227-26 | Top, Rear Hood Cover, 26" | 1 | 1 | | | | | | |
| 17 | S23227-32 | Top, Rear Hood Cover, 32" | | | 1 | 1 | 1 | 1 | | |
| 18 | S23227-38 | Top, Rear Hood Cover, 38" | | | | | | | 1 | 1 |
| 19 | S23216 | Bracket, Ignition Module | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| 20 | S16270 | Halogen Light | 1 | 1 | 2 | 2 | 2 | 2 | 2 | 2 |
| 21 | S16318 | Led, Red | 2 | 2 | 3 | 3 | 4 | 4 | 4 | 4 |
| 22 | S13330 | Infrared Rotisserie Burner | | | | | 1 | 1 | 1 | 1 |
| 23 | S13883 | Stainless Steel Spit Rod (26"/32") | 1* | 1* | 1* | 1* | 1 | 1 | 1 | 1 |
| 24 | S13890 | Stainless Steel Spit Rod (38") | | | | | | | 1 | 1 |
| 25 | S16303 | Safety Thermocouple | | | | | 1 | 1 | 1 | 1 |
| 26 | S16268 | LR Igniter, Rotisserie | | | | | 1 | 1 | 1 | 1 |
| 27 | S22083 | Cover, IR Igniter, Rotisserie | | | | | 1 | 1 | 1 | 1 |
| 28 | S13865 | Stainless Steel Meat Forks | 1* | 1* | 1* | 1* | 1 | 1 | 1 | 1 |
| 29 | S23220-26 | Bottom, Rear Hood Cover, 26" | 1 | 1 | | | | | | |
| 30 | S23220-32 | Bottom, Rear Hood Cover, 32" | | | 1 | 1 | 1 | 1 | | |
| 31 | S23220-38 | Bottom, Rear Hood Cover, 38" | | | | | | | 1 | 1 |
| 32 | S23206 | Baffle, Air Stop | 2 | 2 | 3 | 3 | 3 | 3 | 3 | 3 |
| 33 | S16272 | Battery Pack | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| 34 | S23202-26GY1 | Front Panel, DHBQ26G | 1 | 1 | | | | | | |
| 35 | S23202-32GY1 | Front Panel, DHBQ32G | | | 1 | 1 | | | | |
| 36 | S23202-32RY1 | Front Panel, DHBQ32R | | | | | 1 | 1 | | |
| 37 | S23202-38RY1 | Front Panel, DHBQ38R | | | | | | | 1 | 1 |
| 38 | S23203-26 | 26" Drip Pan Handle | 1 | 1 | | | | | | |
| 39 | S23203-32 | 32" Drip Pan Handle | | | 1 | 1 | 1 | 1 | | |
| 40 | S23203-38 | 38" Drip Pan Handle | | | | | | | 1 | 1 |
| 41 | S13163 | Delta Heat Logo | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| 42 | S14232 | Logo Clip | 2 | 2 | 2 | 2 | 2 | 2 | 2 | 2 |
| 43 | S13162-02 | Delta Heat Knob | 2 | 2 | 3 | 3 | 4 | 4 | 4 | 4 |
| 44a | S13191 | Knob, Bezel, (No Graphics) | 2 | 2 | 3 | 3 | 4 | 4 | 4 | 4 |
| 44b | S13165 | Knob, Bezel, (With Graphics) | 2 | 2 | 3 | 3 | 4 | 4 | 4 | 4 |
| 45 | S12751YN S12751YL | Manifold Assembly (26") NG Manifold Assembly (26") LP | 1 | 1 | | | | | | |
| 46 | S12752GYN S12752GYL | Manifold Assembly (32G") NG Manifold Assembly (32G") LP | | | 1 | 1 | | | | |
| 47 | S12752RYN S12752RYL | Manifold Assembly (32R") NG Manifold Assembly (32R") LP | | | | | 1 | 1 | | |
| 48 | S12753YN S12753YL | Manifold Assembly (38") NG Manifold Assembly (38") LP | | | | | | | 1 | 1 |
| 49 | S16273 | Light Switch | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| 50 | S23229 | Spacer, Briquette Tray | 4 | 4 | 6 | 6 | 6 | 6 | 6 | 6 |
| 51 | S16274 | Spark Igniter (U-Burner) | 1 | 1 | 2 | 2 | 2 | 2 | 2 | 2 |
| 52 | S13365 | Stainless Steel U-Burner | 2 | 2 | 3 | 3 | 3 | 3 | 3 | 3 |
| 53 | S23218-38Y | Briquette Tray Assembly, 26, 38 | 2 | 2 | | | | | 3 / 2 | 3 / 2 |
| 54 | S23218-32Y | Briquette Tray Assembly, 32 | | | 3 | 3 | 3 / 2 | 3 / 2 | | |

Note: * - Optional