

DHBQ-B, REPLACEMENT PARTS LIST

Item No.	TE Part Number	Description	DHBQ 26G-BN	DHBQ 26G-BL	DHBQ 32G-BN	DHBQ 32G-BL	DHBQ 32R/S-BN	DHBQ 32R/S-BL	DHBQ 38R/S-BN	DHBQ 38R/S-BL
1	S13113	Handle Bracket	2	2	2	2	2	2	2	2
2	S13134	Handle Bracket Insulator	2	2	2	2	2	2	2	2
3	S12351	Tube Handle 24.6" S/S Handle	1	1						
4	S12352	Tube Handle 30.6" S/S Handle			1	1	1	1		
5	S12353	Tube Handle 36.6" S/S Handle							1	1
6	S15343Y	Hood Thermometer / Bezel / Nut	1	1	1	1	1	1	1	1
7	S22141	Bracket, Mount Igniter, IR					1	1	1	1
8	S23231-26Y	26" Hood Assembly	1	1						
9	S23231-32Y	32" Hood Assembly			1	1	1	1		
10	S23231-38Y	38" Hood Assembly							1	1
11	S13959	26" Warming Rack	1	1						
12	S13960	32" Warming Rack			1	1	1	1		
13	S13961	38" Warming Rack							1	1
14	S21813	Motor Bracket	1*	1*	1*	1*	1	1	1	1
15	S16340	Rotisserie Motor	1*	1*	1*	1*	1	1	1	1
16	S23227-26	Top, Rear Hood Cover, 26"	1	1						
17	S23227-32	Top, Rear Hood Cover, 32"			1	1	1	1		
18	S23227-38	Top, Rear Hood Cover, 38"							1	1
19	S23216	Bracket, Ignition Module	1	1	1	1	1	1	1	1
20	S16270-1	Halogen Light Bulb	1	1	2	2	2	2	2	2
21	S16318	LED, Red	2	2	3	3	4	4	4	4
22	S13330	Infrared Rotisserie Burner					1	1	1	1
23	S13883	S/S Spit Rod (26"/32")	1*	1*	1*	1*	1	1		
24	S13890	S/S Spit Rod (38")							1	1
25	S16303	Safety Thermocouple					1	1	1	1
26	S16268	I.R Igniter					1	1	1	1
27	S22083	Cover, IR Igniter					1	1	1	1
28	S13865	Meat Forks S/S	1*	1*	1*	1*	1	1	1	1
29	S23220-26	Bottom, Rear Hood Cover, 26"	1	1						
30	S23220-32	Bottom, Rear Hood Cover, 32"			1	1	1	1		
31	S23220-38	Bottom, Rear Hood Cover, 38"							1	1
32	S23206	Baffle, Air Stop	2	2	3	3	3	3	3	3
33	S16272	Battery Pack	1	1	1	1	1	1	1	1
34	S23202-26GY1	Front Panel, DHBQ26G	1	1						
35	S23202-32GY1	Front Panel, DHBQ32G			1	1				
36	S23202-32RY1	Front Panel, DHBQ32R					1	1		
37	S23202-38RY1	Front Panel, DHBQ38R							1	1
38	S23203-26	26" Drip Pan Handle ONLY See S23217-26 both needed	1	1						
39	S23203-32	32" Drip Pan Handle ONLY See S23210-32 both needed			1	1	1	1		
40	S23203-38	38" Drip Pan Handle ONLY See S23217-38 both needed							1	1
41	S13163	Delta Heat Logo	1	1	1	1	1	1	1	1
42	S14232	Logo Clip	2	2	2	2	2	2	2	2
43	S13162-02	Delta Heat Knob, RED *No longer available	2	2	3	3	4	4	4	4
44	S13191	Knob Bezel (No Graphics)	2	2	3	3	4	4	4	4
45	S13165	Knob Bezel (With Graphics)	2	2	3	3	4	4	4	4
46	S12751YN	Manifold Assembly (26") NG	1							
47	S12751YL	Manifold Assembly (26") LP		1						
48	S12752GYN	Manifold Assembly (32G") NG			1					
49	S12752GYL	Manifold Assembly (32G") LP				1				
50	S12752RYN	Manifold Assembly (32R") NG					1			
51	S12752RYL	Manifold Assembly (32R") LP						1		
52	S12753YN	Manifold Assembly (38") NG							1	
53	S12753YL	Manifold Assembly (38") LP								1
54	S16273	Light Switch	1	1	1	1	1	1	1	1
55	S23229	Spacer, Briquette Tray	4	4	6	6	6	6	6	6
56	S16274-1	Spark Igniter (U-Burner)	1	1	2	2	2	2	2	2
57	S13365	S/S U-Burner	2	2	3	3	3	3	3	3
58	S23218-38Y	Briquette Tray Assembly, 26", 38" w/briquettes	2	2					3 / 2	3 / 2
	S23299-38Y	Briquette Tray Assembly, 26", 38" NO briquettes	2	2					3 / 2	3 / 2
59	S23218-32Y	Briquette Tray Assembly, 32" w/briquettes			3	3	3 / 2	3 / 2		
	S23299-32Y	Briquette Tray Assembly, 32" NO briquettes			3	3	3 / 2	3 / 2		